



ITEM	DESCRIPTION	PART #
1	5/16" x 1" Cap Screw.....	0161052
2	Expansion Cap	1701326
3	Diaphragm.....	0991230
4	Front Housing & Worm Cup Assembly.....	1701401
5	End Cap (Front Only)	0991178
6	5/16" x 5/8" Set Screw	0164069
7	Cup	0191024
8	Cone	0191023
9	Worm Gear	1701922
10	Input Bearing Cone	0191029
11	Input Bearing Cup	0191030
12	End Cap Assembly (Front Only)	1781714
13	O Ring Seal (End Cap)	0256029
14	Input Shaft Seal	0258023
15	Rear Housing & Worm Cup Assembly	1701405
16	End Cap (Rear Only)	1781713
17	Snap Ring.....	0257013
18	Output Shaft Bearing Cup	0191026
19	Output Shaft Bearing Cone	0191025
20	Wheel Worm	1700868
21	Worm Gear Key.....	1700853
22	Output Shaft Bearing Cone	0191027
23	Neck and Seal Assembly	1701402
24	Output Shaft Bearing Cup	0191028
25	3/8" x 1-1/4" Cap Screw	0161153

ITEM	DESCRIPTION	PART #
26	Plug, Square Head 1/2" NPT.....	0246094
27	Output Shaft Seal	0258024
28	Axle Assembly (Non-Tow)	1703239
29B	ackup Plate	1701791
30	Plate w/Studs Only	1701963
31	9/16" x 1-13/16" Stud Bolt (Non-Tow)	0164105
32	9/16" Lug Nut (Non-Tow).....	0134039

COMPLETE Front Gearbox Assembly	1701966
COMPLETE Rear Gearbox Assembly	1701965

SPECIALTY GEARBOXES

COMPLETE Heavy Duty Bronze Gearbox Front	1732144
COMPLETE Heavy Duty Bronze Gearbox Rear	1732143
Bronze Gear	1701423
Steel Worm for Bronze Gear	1732140
COMPLETE H.D. Bronze Gearbox Front (Towable)	1732835
COMPLETE H.D. Bronze Gearbox Rear (Towable).....	1732836
COMPLETE Non-Tow Gearbox (Univ. Front & Rear).....	1703321
Worm Gear	1702360
Housing	1701405